

SURFACE PROTECTION

This product has an acrylic PUR polyurethane treatment applied at time of manufacture, and as such is a low maintenance vinyl. This means there is no need to seal or polish when installed, unless there is a requirement for a higher gloss finish, or other aesthetic or hygiene considerations.

INITIAL MAINTENANCE

Remove loose dirt and debris from the newly installed floor using broom or vacuum. Ensure all adhesive residues are removed with due regard to supplier's recommendations. Do not use high abrasive pads or scourers.

Wash floor with a neutral detergent by low speed scrubbing machine fitted with nylon brushes or red pad. Ensure all detergent residues are rinsed and removed from the floor.

DAILY MAINTENANCE

Remove loose dirt with broom or vacuum; damp mop with neutral detergent.

If used as wall vinyl, periodic wiping with a damp cloth should be sufficient for day to day cleaning. Detergents may not be necessary, but if used, should be pH neutral (7), and rinsed off immediately.

If there are any marks occurring as a result of collisions with trolleys etc. can be removed by using a light abrasive steel wool pad and warm water. Be careful not to apply too much pressure, as this can damage the protective layer.

PERIODIC MAINTENANCE

Machine autoscrub with nylon brush as required, or wash floor and buff with red pad at 450rpm. Sealing is a requirement periodically.

Wash floor with a stripping agent by low speed scrubbing machine fitted with blue, green or brown pad according to the dirt level on the floor. Ensure all detergent residues are rinsed and removed from the floor.

Seal the floor with 3 coats of a proprietary brand sealer. Observe manufacturers recommendations in respect of sealer application.

Polish the floor to desired gloss level with a cleaning machine fitted with buff pads.

For further enquiries regarding the maintenance of Gerflor products, please contact your Gerflor Technical Manager.

